

# WarmFlo® Electro-Boiler™

## EB-W-\*\* Series

Replacement Part #	Description
<b>EB-W-13</b>	
5639	GE 30-Amp Circuit Breaker
5640	GE 60-Amp Circuit Breaker
<b>EB-W-18</b>	
5640	GE 60-Amp Circuit Breaker
<b>EB-W-23</b>	
EMR1B8102B	Upperstage Relay Board
5639	GE 30-Amp Circuit Breaker
5640	GE 60-Amp Circuit Breaker
<b>EB-W-27</b>	
EMR1B8102B	Upperstage Relay Board
5640	GE 60-Amp Circuit Breaker

Replacement Part #	Description
<b>Common Parts for the EB-W-** Series (WarmFlo II)</b>	
WF2EB	Control Board
UIC9266 R-096	Microchip v. 2.2* (Specify Code – EBA or EBW)
UIC9266 R-080	Microchip v. 2.3* (Specify Code – EBA or EBW)
WFR3T5616	Relay Board
WFIBT5619B	Pump / Thermostat Board
@WFSST10FT	Supply Sensor ( <i>Boilers Manufactured before 7/2004 – Corresponds with Microchip v. 2.2*</i> )
WFSOF	Outdoor Sensor ( <i>Boilers Manufactured before 7/2004 – Corresponds with Microchip v. 2.2*</i> )
WFSB	Supply Sensor ( <i>Boilers Manufactured after 7/2004 – Corresponds with Microchip v. 2.3*</i> )
WFS25F	Outdoor Sensor ( <i>Boilers Manufactured after 7/2004 – Corresponds with Microchip v. 2.3*</i> )
5533	Sensor Well
4037KIT	50-Amp Triac Kit
5456A	Pressure / Temperature Gauge
5535	205° Manual Reset Limit
5537	190° Auto Reset Limit
EB5520	4.5kW Element with Gasket
UFUSE0440	2-Amp Fast Blow Fuse
5453	30 psi Relief Valve