

Electro-HELPS III

Summary – Electro Field Product Support PC Software

Kit Part Number	Description	Application, End Product	Release Date	PC	Palm	USB
ET-SOFT-WF	All WF II forced air – setups to modify or create chip code and temp evaluation	EM-WU, WD, WE	09-18-08	2.34		
ET-SOFT-WF-USB	Both WF II and TS boiler ①	EM-WU, WD, WE EB-S, EB-W* ③	09-18-08 07-21-04 06-11-07			2.34 3.10 4.10
ET-SOFT-WFP	All WF II forced air – setups to modify or create chip code and temp evaluation	EM-WU, WD, WE	09-22-08		1.6	
ET-SOFT-TS	TS series boilers – setup and temperature troubleshooting	EB-S, EB-W* ③	07-21-04 06-11-07	3.10 4.10		
ET-SOFT-TSP	TS series boilers – setup and temperature troubleshooting	EB-S, EB-W* ③	06-11-07		4.3	
ET-SOFT-GC	Electro GenConnect, automatic – all setups and clock/calendar, error code readout (MS-DOS)	LG-***A***	11-18-02	5.00		
ET-SOFT-GC-USB	Same as above	LG-***A***	11-18-02			5.00
ET-SOFT-GCP	Electro GenConnect, automatic – all setups and clock/calendar, error code readout	LG-***A***	10-22-04		1.2	
ET-SOFT-SP	Electronic submeter – setup, current/volt readout, kWh register, calibration offsets	ET-SP	06-16-04	1.00		
ET-SOFT-SP-USB	Same as above	ET-SP	06-16-04			1.00
ET-SOFT-SPP	Electronic submeter – setup, current/volt readout, kWh register, calibration offsets	ET-SP	07-21-04		1.0	
ET-SOFT-ETDAS	Demand alert – setups for front panel functions and setup for kW profiling	ET-DA	10-18-01	1.10		
ET-SOFT-ETDAP	Demand alert – setups for front panel functions and setup for kW profiling	ET-DA	07-21-04		1.0	
ET-SOFT-KH	Hydron HP setups		11-02-06	2.11		
ET-SOFT-KH-USB	Same as above		11-02-06			2.11
ET-SOFT-KHP	Hydron HP setups		11-02-06		2.2	
ET-SOFT-EMFC	PC fuel comparison		11-15-05	3.21		
-	EB-N, TS & A PC monitor and setups	EB-N*-	09-23-08	1.00	-	-

Palm requirement – it is difficult to specify an exact manufacturer and model number because those things change almost weekly. Most of the computer companies change model and features almost at every production run. If we specify a specific model the chance of your local store or source having that model is probably questionable. Our suggestion is that you use the following criteria to talk to a salesperson or technical representative to make sure the Palm you purchased does have these minimal features:

- OS V3.0 or higher
- At least 17 K available memory
- RS-232 serial communication port
- Typically a cradle or handheld option cable for the RS-232
- This RS-232 cable must have industry standard serial 9-pin socket connector
- Electro Industries provided cable/adaptor (male) plugs into this 9-pin connector

Notes:

- ① Three programs, on same CD, get both, select at entry.
- ② Kit part number includes cable assembly, etc.
- ③ New EB-C (large vessel) models will use ET-SOFT-TS, additional program selections.
- ④ Previous Handheld WF-ANZ2 was limited to forced air only.
- ⑤ Upgrade WF-ANZ5 has switched to select EB-S and EB-W.
- ⑥ GenConnect Handheld is LG-ANZ3.4 (Ver 5.00, 10-8-02).
- ⑦ WarmFlo Mini-Boiler (EMB-W) and WarmFlo Make-Up Air (EM-WX, -WC, -WM) do not have PC or Handheld interface. There are single sensor outlet temperature only products and there is no Handheld or PC plug-in ability.
- ⑧ Digital Electro-Stat is also self-contained and does not have a plug-in PC or Handheld function.